


BANDSAW FENCE



1/4" Flat Head Stove bolt, screwed into a T-NUT INSERTED INTO FENCE.

GLUE & SCREW TOGETHER

TOGGLE CLAMP. CLAMPS FENCE TO FRONT EDGE OF TABLE

MAKE FENCE TO FIT YOUR BANDSAW TABLE.

NOTE: VERY FEW BANDSAWS ACTUALLY CUT PARALLEL WITH THE TABLE. A FENCE MUST BE ADJUSTABLE TO THE BANDSAW'S "ANGLE OF DRIFT". THE STOVE BOLTS IN THE T-NUTS ALLOW YOU TO ADJUST THE FENCE TO THE "A.O.D." TO FIND YOUR SAW'S A.O.D., DRAW A STRAIGHT LINE ACROSS THE CENTER OF A BOARD APP. 10X10. MAKE A FREE HAND CUT ON THIS LINE, STOPPING MIDWAY. WITHOUT MOVING THE BOARD, MARK THE ANGLE ALONG ONE EDGE W/A PENCIL. SET YOUR FENCE TO THIS ANGLE. IT WILL PROBABLY NEVER CHANGE.